

# 90mm Shower Tray Waste Installation and Assembly Instructions

## Disassembly:


1. Gently pull the 'Dome & Inner Section' from the upper assembly in the Bottle-Trap.
2. Unscrew the 'Upper Assembly' from the Bottle Trap & remove Lower seal.

## Assembly / Fitting:

3. Apply copious amounts of a suitable good quality neutral cure silicone or a suitable polymer sealant to the shower tray contact points between the 'Upper Assembly, Lower Seal & Bottle Trap' and then assemble into the outlet hole of the tray to hand-tight only as the thread has a spring-off tolerance to prevent over-tightening.

**Note! Dry assemble all items before fitting to ensure compatibility before applying silicone.**

4. Connect the pipework to the 'Bottle Trap' using the seals supplied and ensure that a watertight seal is achieved.
5. When the silicone has fully dried place the 'Inner Section & Dome' into the 'Upper Assembly' The waste unit and all pipework **MUST** now be pressure tested and checked for water leaks and adequate flow. **DO NOT PROCEED IF NOT SATISFIED.**



# 90mm Shower Tray Waste Installation and Assembly Instructions

These instructions **MUST** be given to the end user upon completion of installation for possible future reference.

## **Before starting, please check the following:**

Please read instructions in conjunction with that supplied with your shower tray.

Check that the intended shower tray outlet hole thickness is within the waste unit's adjustment range of Min 5mm to Max 16mm.

Check that the outlet hole (EN 274) in your chosen shower tray is intended for fitting a 90mm waste unit.

Check that the available recess depth under the tray is big enough to accept the unit and sufficient pipe drop angle is available to permit satisfactory flow in accordance with the building regulations.

Check that the intended pipework (BS EN 1451 required) is compatible with the 40mm push fit connections of this unit.

## **Cleaning:**

Simply disassemble the 'Dome & Inner Section' as described at point 01 above then rinse to remove any trapped hairs and other debris in soapy water only. Reassemble and operate the shower to flush water through the unit.

**Note! To prevent foul air from escaping firstly, ensure that the Inner Section always has water in it. Secondly, ensure that all parts are assembled and that the Dome is fully pushed into the Upper Assembly.**

Customer Care: 0845 5052211  
Monday - Friday 9am-5pm